

Evolution Print® heat transfer paper features a quick peel, making it great for larger projects.

PRINTING

- Use bypass tray or tray if the printer does not have one. Do not stack more than 50 sheets at a time. Air all sheets on both edges to ensure they are loose.
- Set paper type: Label, Transparency, Heavy Paper or Thick Paper mode (depending on printer/copier make and model).
- Use Mirror Image setting so image will be right reading after transferring to the fabric chosen.
- If your printer or copier allows, open the feed option from the back of the printer for straight feed through the printer.

APPLICATION

- Set temperature to 375°F.
- Set to medium-high pressure (approx. 40 lbs.).
- If you prepress, allow fabric to cool completely.
- Position transfer paper on the fabric item and press for 8 seconds.
- Peel transfer sheet immediately and consistently in a diagonal direction.
- If a smooth texture is desired, place a silicone sheet on top of image and press again for 5 seconds.
- Peel silicone sheet hot or cold.

TIP

Use a Heat Press, a conventional home iron will not provide a satisfactory image transfer.

RECOMMENDED FABRICS

White or light-colored:

- Cotton
- Polyester
- Poly/Cotton Blends
- Nylon
- Lycra®

PRINTERS/INKS

Evolution Print laser transfer paper works best with color laser printer and copiers without the use of fuser oil.

APPLICATION

 8 Seconds

 375° F

 Medium-High

 Hot

CARE

- Turn garment inside out.
- Machine wash in warm or cold water.
- Do not use fabric softener or bleach.
- Tumble dry on low setting.
- Do not use iron on imaged area.
- To brighten image on fabric after washing, press with an iron on medium setting.

STORAGE

- Store sheets in the plastic bag until actual use to prevent moisture.
- Close the bag after each use.