

ULTIMATE PRINT LIGHT

Application Instructions

Print full color transfers for light and pastel-colored fabrics. Final transfer will have a soft hand with excellent stretchability and breathability.

PRINTING

- Use the multi-function tray (if applicable).
- Air all sheets on both edges to make sure they are loose.
- 8.5" x 11" or A4 sheets feed short edge first. Be sure to select short edge feed or deselect Long Edge Feed in the Option menu of the Set Up menu.
- 11" x 17" sheets feed short edge.
- Do not stack more than 30 sheets at a time.
- Ensure all sheets are stacked.
- Set paper type.
- Use Mirror Image setting so image will read correctly after transfer to the chosen fabric.
- Open the feed option from the back of the printer for straight feed through the printer (if applicable).

Printing Suggestions:

- HP: Transparency or Label Mode
- Xerox® printers/copiers: Transfer or Coated 1 Mode
- Ricoh® printers/copiers: Thick 2 Mode
- Okidata: Label 1 or Label 2 Mode
- Brother® printers/copiers: Transparency Mode

TIP

Try variations until you get good results with your model of printer or copier. If you don't see your brand of printer or copier, please try one of the suggestions available.

APPLICATION

- Set temperature to 380°F.
- Set at medium high pressure (approx. 60lbs.).
- Do not prepress the fabric. If you do, allow fabric to cool completely.
- Position transfer paper on the fabric with image side toward the fabric and press for 20 seconds.
- Wait 6-8 seconds, peel transfer sheet hot.
- Place a silicone sheet or kraft paper sheet on top of image and press again for 5 seconds.
- Peel silicone sheet or kraft paper sheet hot or cold.

TIP

Use a heat press, a conventional home iron will not provide a satisfactory image transfer.

RECOMMENDED FABRICS

For white or light-colored:

- Cotton
- Polyester
- Poly/Cotton Blends
- Lycra®
- Nylon

STORAGE

Ultimate Print Light laser transfer paper works best with Xerox® EA toner laser color copiers and Oki Data color laser printers.

APPLICATION



20 Seconds



380° F



Medium (60 lbs.)



Hot

CARE

- Turn garment inside out.
- Machine wash in warm or cold water.
- Do not use fabric softener or bleach.
- Tumble dry on low setting.
- Do not use iron on imaged area.
- Do not dry clean.

STORAGE

- Store sheets in the plastic bag until actual use to prevent moisture and dust from accumulating.
- Close the bag after each use.