

Use InkTra® inkjet transfer paper in desktop or wide format inkjet printers compatible with OEM inks and dye pigmented.

**Important: Keep InkTra® transfer paper in the plastic bag until actual use. This will prevent moisture from forming. Close the bag after each use.**

## PRINTING

- In print options, select plain paper as your paper type and turn the mirror image option on or mirror your image with your graphic software.
- Set the printing mode to Photo Quality in Printer Properties.
- Print in either 360 dpi or 720 dpi mode. Do not print higher than 720 dpi; doing so will not enhance the transfer color and may cause bleeding due to excessive dye accumulation.
- After printing, allow the transfer to dry thoroughly for approximately 45 to 60 minutes.

“ There are many different types of inkjet printers on the market, and new ones are being introduced every day. Not all inks work equally well. While our inkjet paper works in MOST inkjet printers, there is no guarantee that the inks will be colorfast.

*We recommend using OEMs or pigmented inks whenever possible. We strongly suggest that you test your inks (wash test) prior to producing multiple transfers to ensure that the ink does not run.*

## PRESSING

- Set temperature to 350°F to 360°F.
- Low-medium pressure.
- Cut the image out and leave a 1/8" border. For items such as mouse pads and coasters, there is no need for cutting.
- Position the transfer paper on the fabric, image facing down.
- Press for 12-16 seconds (peel hot).

### If Pressing With a Home Iron

Set the iron to the hottest temperature. Do not add water to the iron. When ironing onto a T-shirt, double fold the shirt so that the image area is facing upward. Iron the area for a few seconds, without the transfer paper, over a hard surface (not an ironing board). We recommend placing a towel underneath the shirt. Place the image face down onto the fabric. Iron the back of the image for a few seconds and let cool for about 10 seconds.

Iron the perimeter of the image first, starting at the lower left corner and moving upward along the side to the top left corner. Next, iron the top center of the image moving slowly to the bottom center of the image. Re-iron the image VERY SLOWLY using medium to high pressure. Continue ironing until you have completely traced the sides of the image.

This entire process should take about 60-70 seconds for an 8" x 10" (20 cm x 25 cm) image surface. Follow-up by ironing the whole image quickly, heating all of the transfer paper again for approximately 10-13 seconds. Immediately after the ironing process, peel the transfer starting at a corner. CAUTION: HOT

## WASHING:

- Wait 24 hours before using or washing the garment for the first time.
- Turn garment inside out. Machine wash in warm or cold water.
- Do not use fabric softener or bleach. Do not leave garment in washer.
- Tumble dry on low setting.
- Do not line dry or dry clean.
- Do not use iron on imaged area.